

Wide tire four-wheel folding golf cart

User manual



Environment

Safety

Effort

Welcome

- Thank you for choosing the wide tire four-wheel drive golf cart (hereinafter referred to as the golf cart). The golf cart is an intelligent and powerful four-wheel drive walking tool. The four-wheel design structure is stable and suitable for consumer groups of different ages.
- The golf cart has advanced and reliable design technology, energy conservation and environmental protection. There is no pollution and noise during the operation of the golf cart, which is conducive to environmental protection.
- This manual explains the operation of the golf cart. For your safety, please read it in detail and abide by the relevant regulations.
- If your golf cart is transferred, please transfer this manual to new users. New users also need to know this knowledge.
- This manual has been printed as far as possible to include the introduction of various functions and instructions. However, due to the continuous improvement of product functions and design changes, it may still be inconsistent with the products you purchased.

Prohibited matters



- It is prohibited to use in areas where such vehicles are prohibited by the laws of the country / region and relevant management units.
- Do not drive sideways on slopes.
- Overload is prohibited. The standard load capacity is 150 kg.
- It is forbidden for the telescopic parts of the golf cart to exceed the safety warning line.
- It is forbidden to use and store when the ambient temperature is above 40 ° C and below - 20 ° C.
- It is forbidden to push with electricity. Before pushing, it must be ensured that the vehicle is in the state of power failure.
- It is forbidden to turn violently, change the direction greatly and become unstable in the center of gravity, which may lead to danger.
- It is forbidden to drive in bad weather or environment, such as heavy rain, heavy snow and strong wind, and slippery, muddy and other road sections.
- It is forbidden for children under the age of 14 to drive alone (please refer to the local law for the specific legal driving age).
- It is forbidden to use golf carts without safety helmets. Helmets or related protective equipment shall be worn in accordance with local laws and regulations.
- It is forbidden to drive by alcoholics, mental patients, sedative drug users, and people with limited mobility.
- It is forbidden to leave the steering handle with both hands when driving, to lean your body against the steering handle, and to leave the foot pedal during driving.
- It is forbidden to refit the parts of the golf cart at will and drive the refitted golf cart on the road, which will affect the performance of the golf cart and even damage the golf cart.
- It is forbidden to drive in dangerous places, such as fire, gas or explosion, which may be caused by flammable environment.

Special note: do not put the golf cart in the car or in the sealed environment of the trunk in the hot season! Under high temperature, it may lead to complete failure of the battery pack and even combustion!

Safety instructions

Golf cart is a sports entertainment tool, not a vehicle, but once you drive it into a public area, it will also have the attribute of vehicle, so there are possible safety risks of all vehicles. You may face personal injury due to collision and loss of control. To ensure your driving safety, please read all instructions and precautions in this manual completely and carefully.

Note: Although this manual can help you better understand and use the golf cart, we cannot ensure that all types of emergencies are included. Therefore, we remind you to drive carefully to ensure your driving safety.

Please take effective safety measures before driving a golf cart. You must wear safety helmets and other protective equipment. Keep alert during driving and keep a reasonable safe distance from pedestrians and other means of transportation.

When driving in countries and regions where there are no relevant national standards and regulations for golf carts, you must strictly abide by the safety requirements for drivers in this manual. The company will not bear any direct and joint liability for all property and personal losses, accidents, legal disputes and other adverse events causing conflicts of interest caused by violation of the use behavior indicated in this manual.

Please do not lend the golf cart to people who cannot operate it, so as to avoid injury. Please be responsible for your friend's safety. Before handing over the golf cart to your friend for use, please carefully read this manual and tell him that he must wear safety protection to assist him in driving.

Please conduct basic inspection on this product before driving the golf cart every time to confirm that all quick disassembly parts of the golf cart are fastened and the direction control handle is stable. In case of obvious looseness of body parts, air leakage or excessive wear of tires, abnormal steering noise or steering failure, please stop using immediately and do not drive forcibly. Please contact the company for fault diagnosis in time to obtain professional guidance.

Avoid the golf cart from rain or wading. When the rain is immersed or the wading water level is flooded to the wheel hub of the rear wheel motor, the battery will be flooded and the internal circuit will be short circuited. In this case, it is strictly prohibited to charge the golf cart again, otherwise it will cause battery combustion and explosion hazards.

Learn to drive

Practice in a safe and open place until you can get on the bus safely and comfortably, and skillfully control front and rear, turn, stop and get off. Please do not drive the golf cart to the complex driving environment and road conditions until you are proficient in the operation.

There is a risk of falling and injury during study, so please wear safety helmets and protective gear throughout the driving process.

1. Before driving, check whether the power is sufficient, whether the tire pressure is sufficient, and whether the braking performance is intact.
2. NFC card swiping position, and the power indicator light is on. At this time, the power has been connected before driving.
3. Turn the speed control knob back slowly with your right hand to the speed you need to enter normal driving.
4. When you need to stop, first turn back the handle to significantly reduce the speed, then brake, keep the vehicle stationary, NFC card swiping again which means that the power supply has been cut off and the key has been pulled out.
5. After use, please charge according to the remaining power.

The maximum speed of the golf cart can reach 18km / h. It is not allowed to make sharp turns at high speed. If the direction is changed greatly, the center of gravity will become unstable, resulting in the overturning of the golf cart and the risk of falling and injury of drivers.

6. Please start in first gear
7. End driving, turn off the power promptly to avoid battery depletion
8. Charge the battery 5-6 month once if long time not drive.

Steering bar and seat adjustment



- Detachable steering bar and seat adjustment.
- 360 ° seat rotation


Functional diagram



LCD meter assembly, electrified door lock, LED headlamp and power display.
NFC card swiping to open golf cart



The red press is the switch for the light.
Green press the horn to remind pedestrians of accidents and unnecessary traffic.



Speed regulating handle: turn the handle with your right hand to adjust the acceleration and deceleration according to the direction shown in the figure.



Three gear speed change switch: gear I, II and III correspond to 6 / 12 / 18km / h respectively.


Reverse switch "R", press it to reverse gear, and press it again to bounce back to forward gear.



Parking system (hand brake two gear adjustment), press to park to prevent sliding on unstable roads.

Charging method





Cover with a protective cap when not in use →



→ Remove the charging protective second align the positioning groove on the charging port end of the charger with the charging port of the vehicle and insert it, and then Connect the charger plug to an AC power outlet.



Table of technical parameters

Product name	Wide tire four-wheel drive golf cart
Overall dimensions	1040*670*910mm
Packaging size	1180*710*560mm
Motor power	300Wx4
Front / Rear type size	80/60-6 fat tyres
Lithium Battery	36V20Ah /36V25Ah /36V30Ah
Charger	100~240V , 50-60Hz
Charging time	5h / 8h
Max. speed(km/h)	6/ 12/ 18km/h
Turning Radius	1.5m
Max.climbing grade	20°
Max.loading weight	150kgs
Ground Clearance	100mm
Travel Range	25km/30km/40km
N.W / G.W	52kg/45kg
Option parts	golf bag holder

*The actual endurance range is affected by many factors, such as vehicle configuration, load, temperature, wind speed, road surface, operating habits and so on. The data in this manual is for reference only.

*The actual product size and weight will vary slightly due to different measurement methods, assembly tolerances and configurations. The data in this manual are for reference only.

*The technical parameters of golf cart will vary according to the market of different countries and regions. The data in this manual is for reference only. For the technical parameters of golf cart, please refer to the information provided at the actual purchase place.

Maintenance

If there are stains on the surface of the golf cart body, wipe it with clean water or neutral detergent, and then wipe it with a dry cloth.

Tip: do not use alcohol, gasoline, kerosene or other corrosive and volatile chemical solvents for cleaning, otherwise the appearance and internal structure of the car body will be seriously damaged.

It is forbidden to wash with high-pressure water gun to avoid potential accidents caused by wetting of internal electronic components and circuits.

When the golf cart is not in use, try to store it indoors in a dry and cool place, and try to avoid storing it outdoors for a long time. The outdoor environment of sun exposure, overheating and supercooling will accelerate the aging of the appearance and tires of the golf cart and reduce the service life of the golf cart and its battery pack.

Do not disassemble or refit this product by yourself, and the company will not bear all the consequences arising therefrom. It is forbidden to use any spare parts not specified by the company. Once used, you will lose your warranty commitment. If you need to repair or replace parts, please contact the company or local authorized dealer.

Maintenance of golf cart battery pack

Do not put the golf cart in a high temperature of more than 40 °C or a low temperature of less than - 20 °C (for example, do not put this product or its battery pack in a car exposed to the sun in summer). Do not put the battery pack into the fire, otherwise it may lead to battery failure, overheating and even fire risk.

Avoid recharging when the power is completely exhausted, and try to use it as soon as possible, which can greatly prolong the service life of the battery pack. In addition, when used at room temperature, the battery pack can play a higher mileage and performance; If it is used in the environment below 0 °C, the battery life and performance will decline. Typically, at - 20 °C, the range may be half or less than that at room temperature. When the temperature rises, the battery range will be restored.

If you don't use the golf cart for a long time, please pay attention to charging at least once a month to maintain the service life of your battery pack. If the battery is not charged in time for a long time, it is likely to cause excessive discharge and damage, which is unrecoverable.

Note: non professionals are not allowed to disassemble the battery pack at will, otherwise serious safety accidents may be caused by electric shock or short circuit! At the same time, the battery pack cannot be removed at will. If you need to replace the battery, please contact our company or local special dealer, and we will provide you with high-quality professional services.